

19/10/2021

Note: The information provided below is missing from the Ellere Electric Fire User Guides Revisions A and B, but has been included in Revision C. These instructions are intended for the Ellere Electric Fire models only.

Pairing the Ellere remote.

Ellere Electric Fire
Remote Control



Step 1. Press and hold the power button on the Ellere remote control for 7 seconds.

Step 2. You will see the Display shows “88:88”

Step 3. You will hear a “beep” sound from the fireplace The remote and the fireplace have paired successfully